





SERVICE PARTS—WALKER HYDRAULIC JACKS



Series "A"



11



27

21

ORDER BY PART NUMBER, NOT CODE NUMBER

PARTS LIST No. 9534



MANUAL

WALKER SERVICE

We have Factory-owned BRANCHES AND AUTHORIZED SERVICE DEPOTS located in the principal cities of the United States and Canada. They are operated by FACTORY TRAINED STAFFS and carry a comprehensive stock of REPAIR PARTS. Before returning Jacks for service, please contact the Factory or your Walker DISTRIBUTOR for location of Branch or Service Depot nearest you. Walker Branches will be listed under Walker Marketing Corp., and your orders should be directed accordingly.

Note: For quick reference, to locate parts on drawings when part numbers are known, refer to "Numerical Listing" on last page to find proper code number of part on drawings.

Code No.	No. Req'd.	Part No.	Name of Part	Used On Series
1	1	214980	Ram Gland Nut	E
1-A	1	WH-4521	Ram Gland Nut	A
2	1	213298	Ram "O" Ring	E
2-A	2	209840	Ram Packing Ring	A
3	1	214979	Tank Nut	E
3-A	1	WH-5781	Tank Nut	A
4-A	1	210364	Ram Gland Collar	A
5	1	214982	Seal Ring	E
6	1	210651	Tank & Handle Assembly	A-E
7	1	212540	Filler Screw	A-E
8	1	212562	Air Vent Screw	A-E
9	2	200003	Gasket - Filler & Air Vent Screw	A-E
10	1	210637	Ram Cylinder	A-E
11	1	212913	Release Assembly - Complete	A-E
12	1	212549	Release Stem & Cross Pin Assembly	A-E
13	1	214555	Release "O" Ring	A-E
14	1	212227	Release Valve	A-E
15	1	219685	Ram Assembly - Complete	A
15	1	219686	Ram Assembly - Complete	E
16	1	210632	Ram Cap	A-E
17	1	210635	Ram	A
17	1	214981	Ram	E
18	1	WH-4461	Brass Heel Plate - Ram	A-E
19	1	214904	Cup Leather - Ram	A-E
20	1	WH-4441	Nut - Ram Cup	A-E
21	1	213300	Pump Assembly - Complete	A-E
22	1	209910	Retriever Link - Pump	A-E
23	1	213256	Pump Piston	A-E
24	3	201826	Pump Vee Leathers	A-E
25	1	WH-9611	Rubber Spreader - Pump	A-E
26	1	204235	Steel Washer - Pump	A-E
27	1	212170	Pump Nut	A-E
28	1	213263	Base & Support Post Assembly	A-E
29	1	210271	Screen	A-E
30	1	205495	Plug - 3/8" Pipe	A-E
31	1	203198	Suction Ball - 7/32", steel	A-E
32	1	WH-9981	Suction Spacer - Pump	A-E

TRI-CITY HYDRAULIC JACK SERVICE
 4628 N. Florida Avenue
 Tampa, Florida 33603-3700
 (813) 236-8551



NOTE: WALKER WHOLESALE DISTRIBUTORS & DEALERS - When ordering repair parts from Factory or Factory Branches - address orders to WALKER MARKETING CORP.

WALKER MANUFACTURING COMPANY OF WISCONSIN
 RACINE, WIS.

MAKERS OF WALKER JACKS - EXHAUST SILENCERS AND OIL FILTERS

SERVICE PARTS—WALKER HYDRAULIC JACKS

Code No.	No. Req'd.	Part No.	Name of Part	Used On Series
33	1	203201	Discharge Ball - 5/16", steel	A-E
34	1	213260	Discharge Spacer	A-E
35	1	WH-10141	Discharge Spring	A-E
36	1	210311	Plug - 1/8" Pipe	A-E
37	1	213258	Pump Cylinder	A-E
38	1	WH-9931	Pump Cylinder Cap	A-E
39	1	204402	Pump Gland Washer	A-E
40	1	WH-9801	Felt Washer - Pump	A-E
41	2	213262	Pump Pin	A-E
42	2	204426	Pump Cotter Pins	A-E
43	1	213299	Handle Socket & Cross Pin Assembly	A-E
-	1	10610	Handle	A-E

240574 KIT

NUMERICAL LISTING OF PARTS

Part No.	Code No.	Part No.	Code No.	Part No.	Code No.
WH-4441	20	205495	30	213256	23
WH-4461	18	209840	2A	213258	37
WH-4521	1A	209910	22	213260	34
WH-5781	3A	210271	29	213262	41
WH-9611	25	210311	36	213263	28
WH-9801	40	210364	4A	213298	2
WH-9931	38	210632	16	213299	43
WH-9981	32	210635	17	213300	21
WH-10141	35	210637	10	214555	13
		210651	6	214904	19
200003	9	212170	27	214979	3
201826	24	212227	14	214980	1
203198	31	212540	7	214981	17
203201	33	212549	12	214982	5
204235	26	212562	8	219685	15
204402	39	212913	11	219686	15
204426	42			10610	-

ORDER BY PART NUMBER, NOT BY CODE NUMBER


NEW "ANTI-FOAMING"

WALKER*Hydroyl-50**

A SCIENTIFICALLY COMPOUNDED
NON-CORROSIVE OIL ALLOY DEVELOPED
ESPECIALLY FOR USE IN HYDRAULIC JACKS

- ★ Prevents Interior Rusting
- ★ Preserves Cup Leathers
- ★ Prevents Foaming and Air Binding

- ★ Prolongs Jack Life
- ★ Peps up Jack Performance
- ★ Flows at 50° Below Zero (-50°)



WALKER MANUFACTURING COMPANY OF WISCONSIN
RACINE, WISCONSIN