


PARTS BREAKDOWN

Call 1.800.221.9705 for questions concerning performance of the product or other inquiries.



Parts List

Index No.	Part No.	Description	Qty
1	300DL-01A	Retaining Ring	2
2	300DL-02A	Washer	2
3	300DL-03A	Wheel	2
4	300DL-04A	Side Plate Assy	1
5	300DL-05A	Washer 16	2
6	300DL-06A	Hex Nut M16	2
7	300DL-07A	Caster Assembly	2
8	300DL-08A	Retaining Ring 30	2
9	300DL-09A	Hex Bolt M12x25	2
10	300DL-10A	Spring Washer 12 Spring	2
11	300DL-11A	Bolt	2
12	300DL-12A	Spring Washer 18 Spring	2
13	300DL-13A	Nut M12	2
14	300DL-14A	Pull Rod	1
15	300DL-15A	Spring Washer 18	2
16	300DL-16A	Nut M18	2
17	300DL-17A	Handle Socket	1
18	300DL-18A	Torsion Spring	1
19	300DL-19A	Bolt	1
20	300DL-20A	Upper handle	1
21	300DL-21A	Handle Bumper	1
22	300DL-22A	Power Unit Assy	1
23	300DL-23A	Spring	2
24	300DL-24A	Inspection Plate	1
25	300DL-25A	Screws	4

Index No.	Part No.	Description	Qty
26	300DL-26A	Split Pin 4x45	1
27	300DL-27A	Retaining Ring 25	2
28	300DL-28A	Block Linkage	1
29	300DL-29A	Shaft Arm	1
30	300DL-30A	Lift Arm Assembly	1
31	300DL-31A	Bolt	2
32	300DL-32A	Saddle	1
33	300DL-33A	Rudder Saddle Pad	1
34	300DL-34A	Long Linkage	2
35	300DL-35A	Retaining Ring 10	2
36	300DL-36A	Saddle Block	1
37	300DL-37A	Linkage Axle	1
38	300DL-38A	Bolt	1
39	300DL-39A	Lower Handle	1
40	300DL-40A	Top Cover	1