


Hein-Werner

MODEL AL-38 2½ TON AIR JACK REPAIR PARTS LIST

Order by PART NUMBER—not the item number—and give complete name of part and model number of jack. Item numbers shown on parts photos are only for your convenience in locating the part on parts list. Order repair parts direct from nearest Official Service Station.



REV. 4-1-68

USE NEW PART NUMBER ONLY WHEN ORDERING PARTS

Order parts from the nearest Hein-Werner Official Service Station. Always state both model and serial number.

AL-38

ITEM NO.	OLD PART NO.	NEW PART NO.	DESCRIPTION	ITEM NO.	OLD PART NO.	NEW PART NO.	DESCRIPTION
1	#10-24x1 $\frac{1}{8}$	27285	Rd. Hd. Machine Screw (8)	30	$\frac{5}{16}$ -24x $\frac{5}{8}$	26575	Hex Hd. Capscrew (2)
2	#10	24160	SAE Washer (8)	31	55215	13715	Caster
3	AL114	16090	Saddle Pad (2)	32	1218-00	1915	Shakeproof Lockwasher (3)
4	10A162	546	Saddle Assembly (2)	33	$\frac{3}{16}$ -24	26545	Hex Jam Nut
5	C430-1024-27	16510	Speednut (8)	34	5528R	13830	Grips
6	AL47230	40965	Lift Arm	35	AL144	16627	Valve
7	10A156	533	Carriage Assembly	36	$\frac{3}{8}$ -16x4	26231	Hex Hd. Capscrew (2)
8	1224-00	2155	Shakeproof Lockwashers (2)	37	10A159	541	Handle Assembly
9	$\frac{1}{2}$ -13	25335	Hex Jam Nuts (2)	38	S142	20876	Spring
10	$\frac{3}{8}$ -16	26195	Hex Jam Nut (2)	38A	$\frac{1}{4}$ x $\frac{5}{8}$	25741	Roll Pin
11	1220-00	2095	Shakeproof Lockwasher (2)	39	10A163	543	Safety Release Lever Assembly
12	5100-75	13095	Truarc Ret. Ring (8)	40	$\frac{1}{4}$ x1	25764	Roll Pin (2)
12A	IR1212	18544	Inner Race (4)	41	AL04237	40943	Pipe
13	AL42249	40981	Thrust Washer (4)	42	$\frac{3}{8}$ x3	26412	Roll Pin
14	B1612	16431	Bearings (4)	43	AL04236	40942	Crosstie
15	AL04268	40989	Roller (4)	44	$\frac{3}{8}$ x1	26409	Roll Pin (2)
16	AL48250	40966	Roller Axle (4)	45	4020-21	12760	Crane Wiper
17	$\frac{1}{2}$ -13NCx3 $\frac{1}{2}$	25361	Hex Hd. Capscrews (2)	46	$\frac{3}{8}$ -16x $\frac{1}{2}$	26220	Slotted Rd. Hd. Machine Screw
18	5100-75	13095	Truarc Ret. Ring (8)	47	AL11217	40961	Top Nut
19	10A165	540	Rt. Drag Link Assembly	48	10A155	532	Ram Tube Assembly
20	$\frac{3}{8}$ -16x1	26180	Flat Hd. Machine Screw (2)	49	AL16214	40983	Ram Piston
21	10A158	535	Left Drag Link Assembly	50	AL34215	40982	Cup
22	$\frac{3}{8}$ -16	26170	Reg. Hex Nut (2)	51	AL137	16205	Washer (2)
23	1220-00	2095	Shakeproof Lockwashers (2)	52	AL04216	40967	Lubricating Washer
24	AL04242	40948	Safety Catch (2)	53	$\frac{3}{4}$ -16	26110	Hex Jam Nut
24A	$\frac{1}{4}$ x1 $\frac{1}{4}$	25905	Roll Pin (2)	54	1B792	8845	Axle
25	$\frac{3}{8}$ -16x $\frac{3}{4}$	26175	Hex Hd. Capscrew (2)	55	2x8	24260	Semipneumatic Wheels (2)
26	10A151	528	Frame Assembly	56	Y119A	24490	Clips (2)
27	$\frac{5}{16}$ -18	26455	Reg. Hex Nut	57		80284	Decal (Not Shown)
28	1218-00	1915	Shakeproof Lockwashers (3)				
29	55456	14120	Spring				

REV. 4-1-68

USE NEW PART NUMBER ONLY WHEN ORDERING PARTS

Order parts from the nearest Hein-Werner Official Service Station. Always state both model and serial number.