



INDEX NO.	DESCRIPTION	PART NO.	REQ'D NO
1	Allen Socket Cap Screw	282601	8
2	Air Cylinder Cover	282602	1
3	Spring	282603	1
4	Screw	282604	1
*5	Gasket	282606	2
6	Air Cylinder Housing	282607	1
7	Rubber Stopper	282537	1
*8	Backup Ring	282531	2
9	Allen Socket Cap Screw	282538	3
10	Rear Air Piston Half	282536	1
11	Shuttle Valve	282534	1
12	Spring	282608	1
*13	O-ring	282533	1
*14	O-ring	282507	1
15	Front Air Piston half	282532	1
16	Spring	282609	1
17	Hydraulic Piston	282611	1
*18	O-ring	282612	1
19	Piston Washer	282613	1
20	Washer	282614	1
21	Pump Cylinder Cap	282616	1
*22	Backup Ring	282617	1
*23	U-Cup Seal	282618	1
24	Pump Housing	282619	1
*25	O-ring	282621	1
26	Hydraulic Base	282622	1
27	Retaining ring	282623	1
28	Oil Inlet Valve Stud	282624	1
29	Spring	282626	1
*30	Checkball	282502	2
31	Oil Inlet Valve Filter	282627	1
32	Retaining Ring	282628	1
33	Retaining Ring	282629	1
34	Release Valve	282486	1
*35	O-ring	282487	1
36	Spring	282488	1
37	Valve Guide	282489	1
*38	Backup Ring	282491	2
*39	O-ring	282492	2
40	Pin	282493	1
41	Valve Stem	282494	1
*42	Checkball	282496	1
43	Spring	282497	1
*44	O-ring	282414	2
*45	Backup Ring	282498	1
46	Housing	282499	1
47	Spring	282501	1
48	3/8" NPT Pipe Plug	282677	1
49	Silencer	282632	1
50			

INDEX NO.	DESCRIPTION	PART NO.	REQ'D NO
51	Retaining Ring	282634	1
52	Screw	282636	1
53	Valve Cartridge	282508	1
*54	Checkball	282637	1
55	Stud	282638	1
56	Spring	282639	1
57	Screw	282641	1
58	Screw	282642	2
59	Air Inlet Valve Seat	282643	1
60	Rubber Bushing	282647	1
61	Air Inlet Valve	282644	1
62	Washer	282646	1
63	Air Inlet Valve Cap	282647	1
64	Screw	282648	1
*65	Retaining Ring	282649	1
66	Spring	282651	1
67			
68	Air Manifold	282652	1
69	Foot Pedal Axle	282476	1
70	Retaining Ring	282474	2
71	Allen Socket Cap Screw	282482	2
72	Allen Socket Cap Screw	282477	2
73	Washer	282478	2
74	Pressure Plate	282479	1
75	Silencer	282653	1
76	Wiper	282654	1
77	Reservoir Cover	282656	1
78	Screw	282657	14
79	Air Vent Plug	282686	1
81	Pipe Plug	282661	1
*83	Hydraulic Base Gasket	282663	1
*84	Air Manifold Gasket	282664	1
*85	Reservoir Cover Gasket	282666	1
86	Reservoir	282667	1
87	Pump Pedal	282472	1
*88	O-ring	282484	1
89	Washer	282668	1
90			
91	Gasket Wiper	282481	1
92			
93	Poppit Valve Housing	282672	1
94	Washer	282673	14
95	Poppit Valve Assembly, Small Orifice	282674	1
96	Poppit Valve Assembly, Large Assembly Repair Kit	282675	1
		282605	1

\* The asterisk designates those parts included in the part number 282605 repair kit.

**REPLACEMENT PARTS**

**MODEL NO. 910130A**

**CAPACITY 10,000 PSI**

**DESCRIPTION AIR/HYDRAULIC FOOT PUMP**

