



SPARE PARTS LIST

2 Ton Hydraulic Service Jack


Model # 21020

ITEM	PARTCODE	DESCRIPTION	QTY	ITEM	PARTCODE	DESCRIPTION	QTY
1.	G89-0-0400-2100	base	1	41.	540-4-0404-0000	cotter pin	1
2.*	590-1-0044-5000	o-ring	1	42.	530-3-0001-2000	lock washer	6
3.*	590-4-0045-0000	back-up ring	1	43.	G93-1-0001-0000	bolt	4
4.	G07-0-0400-2100	cylinder	1	44.	G93-1-0500-0000	rear caster assy.	2
5.	G93-1-0701-5000	filter	1	45.	G93-1-0400-0000	bearing	2
6.*	590-1-0063-5000	o-ring	2	46.	G93-1-0001-1000	bolt	1
7.	G07-0-0400-3000	reservoir	1	47.	530-6-0002-0000	lock washer	2
8.	590-5-0010-0100	filler plug	1	48.	520-6-0001-2000	nut	2
9.*	590-2-0041-2000	u-cup	1	49.	G08-0-0300-0100	r.h side plate assy.	1
10.*	590-4-0026-0000	back-up ring	1	50.	520-4-0000-8000	nut	2
11.	G93-1-0700-2000	ram bearing	1	51.	530-3-0000-8000	lock washer	2
12.	G07-0-0400-1000	piston rod	1	52.	530-5-0001-5000	retaining ring "E"	2
13.	G93-1-0700-3100	top nut	1	53.	530-1-0002-0000	washer	2
14.*	590-1-0031-6000	o-ring	1	54.	G93-4-0000-1000	front wheel	2
15.	G93-1-0701-4100	pump piston	1	55.	G93-4-0000-2000	front axle	1
16.*	590-4-0015-0000	back-up ring	2	56.	G93-1-0000-7000	tie rod	1
17.*	590-1-0015-0000	o-ring	2	57.	G08-0-0200-0100	l.h side plate assy.	1
18.	560-1-0063-5000	steel ball	2	58.	G93-4-0000-3000	bolt	1
19.	560-1-0095-2000	steel ball	1	59.	G93-1-0800-3000	connection bar	1
20.*	590-1-0008-2000	o-ring	1	60.	G93-1-0800-1000	handle fork	1
21.*	590-4-0009-0100	washer	1	61.	530-1-0000-8000	washer	1
22.	G61-0-0300-1000	bolt	1	62.	540-4-0201-0000	pin	1
23.	G89-0-0400-1100	washer	1	63.	G93-1-0000-9000	return spring	1
24.	530-6-0000-6000	lock washer	1	64.	520-6-0001-0000	nut	1
25.	510-4-0600-8000	hex bolt	1	65.	G93-1-0800-2000	release valve gear	1
26.*	590-1-0010-3000	o-ring	1	66.	510-2-1001-6000	bolt	1
27.	G89-0-0410-0100	release valve assy.	1	67.	530-3-0001-0000	lock washer	1
28.	G93-1-0700-4000	needle	1	68.	G93-1-0001-4100	pin	1
29.	G93-1-0700-5000	safety spring	1	69.	G93-P-0000-2000	return spring	1
30.	G93-1-0700-6000	safety valve screw	1	70.	G93-P-0000-1000	foot pedal	1
31.*	590-5-0018-0000	seal	1	71.	G93-1-0900-0000	handle assy. (I)	1
32.	G93-1-0700-7000	protection screw	1	72.	510-2-0603-4000	hex. bolt	1
33.	510-9-1000-8000	hex. socket set screw	1	73.	G93-1-0001-5000	handle assy. (II)	1
34.	G07-0-0000-2000	spring	1	74.	G93-3-0000-1000	handle grip	1
35.	530-4-0001-8000	stud radius link	2	75.	G89-0-0400-0000	hyd. power unit	1
36.	G08-0-0000-3000	parallel link	2	**.	G8901S100	repair kits	1
37.	540-4-0302-5000	cotter pin	2	Repair kits includes 2, 3, 6, 9, 10, 14, 16, 17, 20, 21, 26, 31			
38.	530-1-0001-6000	washer	2				
39.	G08-0-0000-1100	saddle	1				
40.	G08-0-0100-0000	lifting arm	1				



2 Ton Hydraulic Service Jack

Model # 21020



Exploded Drawing
2nd Edition ©Jan 2004