
REPAIR PARTS

Sears 1 1/4 Ton Floor Service Jack
Model Number 250.12600



KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	212005	Upper Handle Assy	22	9001	Check Ball-.219 dia	43	212134	Pin-Spacer
2	212010	Lower Handle Assy	23	3037	Fill Plug	44	212206	Axle
3	212025	Handle Base Assy *Incl:*	24	8011	Fill Plug Seal	45	212204	Bushing
4	212067	Handle Base	25	3002	Screw	46	212212	Handle Base Hinge Rivet
5	212035	Snap Lock Assy	26	212101	Oil Block	47	2003	Snap Ring
6	7026	Pin-Roller	27	212103	Freeze Plug	48	212207	Wheel
7	212027	Roller	28	212211	Overload Spring Cap	49	1001	Nut
8	3034	Screw	29	4004	Spring	50	2001	Lockwasher
9	2004	Washer	30	3025	Set Screw	51	3034	Screw
10	212100	Oil Block Assy *Incl:*	31	8001	Seal-Teflon	52	2004	Washer
11	212050	Release Valve Assy	32	4005	Spring	53	6002	Rivet
12	8003	Release Valve Cup Packing	33	3005	Screw-Spring Retainer	54	212202	Plate-Left Side
13	9002	Check Ball-.250 dia	34	8002	Seal-Copper	55	212201	Plate-Right Side
14	212064	Cap-Pump Piston	35	8004	Ram Cup Packing	56	212146	Trunion Arm
15	7003	Pin	36	212131	Ram	57	212163	Control Arm
16	4003	Spring	37	212120	Cylinder Tube Assy	58	212161	Saddle Base
17	212063	Body-Pump	38	212123	Wiper Ring	59	212162	Saddle
18	212061	Pump Piston	39	212147	Trunion	60	6005	Rivet
19	8009	Pump Piston Cup Packing	40	7010	Expansion Pin	61	212134	Pin-Spacer (Hinge Pin)
20	212066	Retainer-Ball	41	4006	Spring	62	212140	Elevator Arm Assy
21	4009	Pump Port Spring	42	3002	Screw	63	13001	Grease Fitting