



10 TON - 365
20 TON - 375



TRI-CITY HYDRAULIC JACK SERVICE
4628 N. Florida Avenue
Tampa, Florida 33603-3700
(813) 236-8551



SPARE PARTS LIST



TRI-CITY HYDRAULIC JACK SERVICE

4628 N. Florida Avenue
Tampa, Florida 33603-3700
(813) 236-8551

MODELS 365 · 375

CAPACITY 10 · 20 TONS.

IMPORTANT

ORDER BY PART NUMBER AND NAME

REF. NR	DESCRIPTION PART NAME	MOD. 10T/365			MOD. 20T/375		
		QT	NR	PÇ	QT	NR	PÇ
01	Nut	16	873500	16	873500		
02	Washer	16	806070	16	806070		
03	O-Ring	02	862329	02	862330		
04	Head Nut	01	981121	01	981200		
05	Plug	01	982002	01	982002		
06	O-Ring	02	862113	02	862113		
07	O-Ring	02	862156	02	862256		
08	Spacer	01	910360	01	910402		
09	O-Ring	01	862154	01	862100		
10	Oil Filter	01	828010	01	828010		
11	Valve	01	698121	01	698201		
11C	Valve, Compl. (3,9 thru 11)	01	698120	01	698200		
12	O-Ring	04	862110	04	862110		
13	Oil Pipe	02	970120	02	970200		
14	Piston Rod	01	691127	01	691207		
14C	Lift Piston (14 thru 19)	01	691126	01	691206		
15	O-Ring	01	862120	01	862123		
16	Piston Collar	01	931121	01	931200		
17	Cup	01	832354	01	832464		
18	Washer	01	905120	01	905200		
19	Track Ring	01	804130	01	804135		
20	Drawbar	04	927073	04	927076		
21	Cylinder Tube	01	916122	01	916200		
22	Bolt	01	866303	01	866303		
23	Spring	01	856102	01	856102		
24	Ball	01	824020	01	824020		
25	Pump Housing	01	907121	01	907200		
26	Ball	02	824030	02	824030		
27	Packing	01	832205	01	832205		
28	Release Valve Shaft	01	688128	01	688128		
29	Oil Filter	01	828011	01	828011		
30	Washer	01	905121	01	905121		
31	O-Ring	01	862122	01	862122		
32	Pump Cylinder	01	915120	01	915120		
33	Cup	01	832115	01	832115		
34	O-Ring	01	862117	01	862117		
35	Dust Seal	01	835010	01	835010		
36	Pump Piston	01	689127	01	689127		
36C	Pump Piston, Compl. (33 thru 36)	01	689126	01	689126		
37	Overload Valve	01	699126	01	699206		
38	Plug	01	982001	01	982001		
39	Axle	01	927098	01	927098		

REF. NR	DESCRIPTION PART NAME	MOD. 10T/365			MOD. 20T/375		
		QT	NR	PÇ	QT	NR	PÇ
40	Track Ring	06	804012	06	804012		
41	Axle	01	927097	01	927097		
42	Spring	01	856707	01	856707		
43	Pump Beam	01	929121	01	929121		
44	Spring	01	856709	01	856709		
45	Axle	01	927091	01	927091		
46	Axle	01	927100	01	927100		
47	Axle	06	927099	06	927099		
48	Track Ring	02	804155	02	804163		
49	Axle	01	927340	01	927390		
50	Track Ring	04	804131	04	804131		
51	Caster	02	693126	02	693126		
52	Frame Side, Right	01	684126	01	684206		
53	Frame Side, Left	01	684127	01	684207		
54	Nut	02	873970	02	873990		
55	Washer	02	806270	02	806310		
56	Track Ring	04	804125	04	804125		
57	Axle	01	927342	01	927391		
58	Nut	02	873800	02	873800		
59	Washer	02	806131	02	806131		
60	Spacer	02	910215	02	910215		
61	Wheel	02	973120	02	973120		
62	Axle	01	927212	01	927212		
63	Axle	01	927185	01	927184		
64	Saddle Carrier	01	694126	01	694126		
65	Link	02	983051	02	983052		
66	Lift Arm	01	675126	01	675206		
66C	Lift Arm, Compl. (50, 56, 63 thru 66)	01	676126	01	676206		
67	Saddle	01	670126	01	670126		
68	Spring	02	856680	02	856680		
69	Tension Pin	01	871131	01	871131		
70	Cover	01	921120	01	921200		
71	Grip	02	686053	02	686053		
72	Nut	02	873100	02	873100		
73	Bolt	02	866119	02	866119		
74	Handle, Compl.	01	678126	01	678126		
75	Washer	02	806040	02	806040		
76	Bolt	04	866307	04	866307		
—	Repair Kit (3, 6 (2 pç), 7 (2 pç), 9, 12 (4 pç), 15, 17, 27, 31, 33, 34, 35)		683126		683206		
—	Hydraulic Unit (1 thru 38)		696126		696206		
—	Hydraulic Unit, Compl. (1 thru 46)		697128		697208		