

Do No 900 1937

Service Parts and Prices Walker No. 810, Series A, B, C, Hydraulic Jack

Price List No. 8102, Effective June 25, 1936

(Supersedes Price List No. 8101, dated December 1, 1932.)

Prices and Specifications Subject to Change Without Notice

Prices are F. O. B. Racine

AUTHORIZED WALKER SERVICE STATIONS

Atlanta, Georgia
Boston, Massachusetts
Chicago, Illinois
Cleveland, Ohio
Dallas, Texas
Kansas City, Missouri
Los Angeles, California

Prior Tire Company
Harvey Sales & Service Company
Illinois Auto Electric Co.
Cleveland Ignition Co.
Beard & Stone Electric Co.
Beach Wittman Co.
Moran & McMenemy


Minneapolis, Minn.
New York, New York
Philadelphia, Pennsylvania
San Francisco, California
Seattle, Washington
Toronto, Ontario, Canada
Winnipeg, Man., Canada

Carburetor Parts & Electric Co.
Equipment & Service Corporation
Auto Equipment & Service Co.
Kinnick Hardware
Universal Repair Shop
The Motor & Tire Works
Beaumont Electric Ltd.

WALKER MANUFACTURING COMPANY

Racine, Wisconsin, U. S. A.

BORDEN-AICKLEN
AUTO SUPPLY CO., Inc.
613-7 BARONNE STREET
RA. 62-7-8-9 N. O. 13. LA.



*Obsolete -
No METAL PARTS
AVAILABLE*

Parts and Prices—Walker No. 810, Series A, B, and C, Hydraulic Jack

| Name of Part | Used on Series | Changes and Replacements | List Price Each | Wt. lbs. oz. | Part No. | Name of Part | Used on Series | Changes and Replacements | List Price Each | Wt. lbs. oz. | |
|--------------------------------|----------------|--------------------------|-----------------|--------------|---------------------|--|----------------|--------------------------|-----------------|--------------|---|
| B- Spring—Discharge Valve | ABC | | n/c | 1 | WH-4971 | Cup Leather—Pump | ABC | was WH- 671* | .15 | | |
| WH-161 Cylinder | ABC | | 1.75 | 12 | WH-5081 | Cup Leather—Ram | ABC | was WH- 151* | .30 | | |
| WH-162 Base | ABC | | 4.85 | 4 | Z- 92 | Pin—Spring (Handle Socket) | ABC | | n/c | 1 | |
| WH-163 Ram | ABC | | .50 | 1 | Z- 107 | Cotter Pin (2) | ABC | | n/c | 1 | |
| WH-164 Cover | A | now WH- 103* | | | Z- 266 | Drive Rivets—Name Plate | AB | now Z- 643* | n/c | 1 | |
| WH-165 Pump Piston | ABC | | .30 | 4 | Z- 306 | Cap Screw—Cover (4) | ABC | | .05 | 1 | |
| WH-166 Packing Nut—Ram | ABC | | .20 | 1 | Z- 346 | Nut—Pump Piston | ABC | | n/c | 1 | |
| WH-167 Packing Nut—Pump Piston | ABC | | .20 | 1 | Z- 507 | 1/4 Allen Plug | ABC | now Z- 628* | .05 | 1 | |
| WH-168 Handle Socket | A | now WH- 62 | | | Z- 508 | 1/4 Allen Plug | ABC | now Z- 629* | .05 | 1 | |
| WH-169 Collar—Packing | ABC | | .15 | 1 | Z- 509 | 1/8 Ball | ABC | | .05 | 1 | |
| WH-170 Collar—Ram | ABC | | .10 | 2 | Z- 510 | 1/8 Ball (2) | ABC | | n/c | 1 | |
| WH-171 Handle Socket | BC | was WH- 42 | .65 | 11 | Z- 511 | Pivot Screw | A | now Z- 541 | .05 | 1 | |
| WH-172 Release Rod | A | see WH-1321* | | | Z- 512 | Pin—Latch | ABC | | n/c | 1 | |
| H- 81 Release Pin | A | now WH-1361 | | | Z- 530 | 1/4 Pipe Plug (Screw Head) | ABC | | n/c | 1 | |
| H- 91 Plug—Release Valve | A | now WH-1371* | | | Z- 539 | Headed Pin | BC | was WH- 111* | n/c | 1 | |
| H- 101 Latch | ABC | | n/c | 1 | Z- 541 | Fulcrum Pin | BC | was Z- 511 | n/c | 1 | |
| H- 103 Cover | BC | was WH- 13* | 2.60 | 2 | Z- 552 | 3/8 Hubbard Plug | BC | was Z- 508 | n/c | 1 | |
| H- 111 Pin—Pump Piston | A | now Z- 539* | | | Z- 561 | 3/8 Release Ball | BC | | n/c | 1 | |
| H- 121 Name Plate | A | see WH-1011 | | | Z- 628 | 1/4 Allen Plug | ABC | was Z- 507* | n/c | | |
| H- 131 Packing—Ram Gland (2) | ABC | | .05 | 1 | Z- 629 | 1/4 Allen Plug | ABC | was Z- 508* | .10 | | |
| H- 141 Packing—Pump Gland (2) | ABC | | .05 | 1 | Z- 643 | Drive Rivets—Name Plate (2) | C | was Z- 266* | n/c | 1 | |
| WH- 151 Cup Packing—Ram | ABC | now WH-5031* | .25 | 1 | 10302 | Handle | | .70 | 2 | 5 | |
| WH- 161 Gasket—Base Flange | ABC | | n/c | 1 | | | | | | | |
| WH- 171 Spring—Suction Valve | A | now WH-1401* | | | | | | | | | |
| WH- 181 Spring—Safety Valve | AB | now WH-1841* | | | | | | | | | |
| WH- 191 Spring—Release Valve | ABC | | n/c | 1 | AP- 511 | Release Rod Assembly | C | | .20 | 3 | |
| WH- 201 Spring—Release Rod | ABC | | n/c | 1 | 1-WH-1391 1-WH-1381 | Hdl. Socket Complete | A | now CP- 157 | | | |
| WH- 211 Spring—Handle Socket | ABC | | n/c | 1 | CP- 143 | 1-WH- 42 1-WH- 101 1-WH- 111 1-Z- 92 1-Z- 512 1-WH- 941 1-WH- 211 2-Z- 107 | | | | | |
| WH- 221 Washer—Air Valve | A | see WH-1311* | | | CP- 150 | Pump Piston Assembly | ABC | | .60 | 7 | |
| WH- 231 Ad. Plug | ABC | | n/c | 1 | CP- 157 | 1-WH- 21 1-WH- 661 1-WH-4971 1-Z- 346 | BC | was CP- 143 | 1.00 | 1 | 2 |
| WH- 241 Cap | ABC | | .15 | 3 | CP- 170 | Hdl. Socket Assembly 1-WH- 62 1-WH- 101 1-WH- 211 1-WH- 941 1-Z- 92 1-Z- 107 1-Z- 512 1-Z- 539 | | | | | |
| WH- 601 Cap—Pump Cup | ABC | | n/c | 1 | | Oil Tank Assembly | BC | | 7.50 | 6 | 3 |
| WH- 671 Pump Cup Washer | ABC | now WH-4971* | .20 | 1 | | 1-B- 661 1-WH- 1 1-WH- 3 1-WH- 161 1-WH- 191 1-WH- 231 1-WH-1121 1-WH-1131 1-WH-1361 1-WH-1371 1-WH-1401 1-WH-1841 1-WH-2151 1-Z- 628 1-Z- 629 1-Z- 509 2-Z- 510 1-Z- 530 1-Z- 552 1-Z- 561 | | | | | |
| WH- 711 Guide—Safety Valve | AB | now WH-2151* | | | | | | | | | |
| WH- 941 Spring—Handle Socket | ABC | | n/c | 1 | | | | | | | |
| WH- 951 Button—Release Rod | ABC | | .05 | 1 | | | | | | | |
| WH-1011 Name Plate | B | now WH-1781 | | | | | | | | | |
| WH-1121 Screen | BC | | .05 | 1 | | | | | | | |
| WH-1131 Screen Plug | BC | | .05 | 1 | | | | | | | |
| WH-1811 Cup Washer | B | now WH-1391* | | | | | | | | | |
| WH-1321 Release Rod | B | now WH-1381* | | | | | | | | | |
| WH-1361 Release Pin | BC | was WH- 81* | .20 | 1 | | | | | | | |
| WH-1371 Release Valve Plug | BC | was WH- 91* | .10 | 1 | | | | | | | |
| WH-1381 Release Rod | C | was WH- 71* | .10 | 2 | | | | | | | |
| WH-391 Washer—Air Valve | C | was WH- 221* | .10 | 1 | | | | | | | |
| WH-401 Spring—Suction Valve | BC | was WH- 171* | n/c | 1 | | | | | | | |
| WH-1781 Name Plate | C | was WH- 121 | n/c | 1 | | | | | | | |
| WH-1841 Spring—Safety Valve | C | was WH- 181* | n/c | 1 | | | | | | | |
| WH-2071 Instruction Decal | C | | n/c | 1 | | | | | | | |
| WH-2151 Safety Valve Adapter | C | was WH- 711* | .05 | 1 | | | | | | | |
| WH-2751 Oil Level Decal | C | | n/c | 1 | | | | | | | |

*Old and new part interchangeable.

SERVICE SUGGESTIONS TO USERS

- Keep ram and pump piston packing nut fairly tight.
- Keep jack closed (ram down) when not in use.
- Check oil level from time to time—when the jack is closed and in an upright position, the oil level should come up even with Filler Plug (Z-530).
- Keep jack clean and free from rust.

OIL TO USE

- 1st Choice—Walker Hydraulic Oil.
 - 2nd Choice—Refrigerator Oil.
 - 3rd Choice—Light Engine Oil.
- If engine oil is used in cold climate, add 50% penetrating oil.
Don't use brake fluid or other fluids containing alcohol.