REPAIR PARTS SHEET

PORTABLE LIFT JACK
MODEL J-17

RATED CAPACITY
1½-TON

Sheet No. 1220 — Issued Mar. 1951
Supersedes Sheet No. 1145 (2-49)

BLACKHAWK





REPAIR PARTS SHEET FOR J-17 HYDRAULIC LIFT POST

Parts List on Reverse Side

PARTS LIST FOR MODEL J-17

REPAIR PARTS SHEET
PORTABLE LIFT JACK
MODEL J-17
RATED CAPACITY
1½-TON
Sheet No. 1220 — Issued Mar. 1951
Supersedes Sheet No. 1145 (2-49)

Item No.	Part No.	Part Name	No. Req.
1	J17.05	Body	1
2	J17.12	Locating Pin	1
3	1.16	7/32" Dia. Ball	1
4	S1.16	5/16" Dia. Ball	1
5	S1.183	Outlet Valve Spring	1
6	S1.167B	Gasket	2
7	J17.185	Valve Plug	1
8	J17.75	Pump Packing	3
9	J17.54	Pump Packing Nut	1
10	AA10.55	Pump Cup Retaining Nut	1
11	BM1.52	Pump Cup Spreader	1
12	BM1.53	Pump Cup	1
13	J17.51	Pump Plunger	1
14	(Same as Item 6)		
15	J17.23A	Filler Plug Gauge	
16	P200.335	Release Valve Packing Washer	1
17	P200.74	Release Valve Packing	2
18	P200.11	Release Valve Packing Nut	1
19	J17.10A	Release Valve Spindle	1
20	P208.57	Pump Plunger Cross Pin	1
21	J17.60	Beam	1
22	CB9.57	Beam Pin	1
23	1.58	Cotter Pin	1
24	J17.268	Oil Tube	1
25	J17.40	Plunger	1
26	J71	Plunger Disc	1
27	MJ41-1	Plunger Cup	1
28	L7.43	Spreader	1
29	J17.123	Hex Slotted Nut	1
30	J17.58	Cotter Pin	1
31	J17.30-1	Cylinder	1
32	J17.25-1	Reservoir	1
33	J17.20-1	Reservoir Cap	1
34	TA7.76	Packing	3
35	J17.21-2	Gland Nut	1
36	J17.447	Inner Guide Sleeve	1
37	J17.446	Outer Guide Sleeve	1
38	J17.80-1	Toe	1
39	J18.35	Clamp Screw Nut	1
40	J14.65A	Clamp Screw	1
41	J17.01	Sub-base	1
42	S8.222	Lock Washer	1
43	S38.181	Plunger Lock Nut	1
44	J17.174	Jack Wheel	2
45	J17.175	Jack Wheel Pin	2
46	K18.58	Cotter Pin	2
47	R330.488	Tapping Screw	4
48	P208.70	Handle	1
49	P208.550	Handle Grip	1
50	1.26E	Name Plate	1
51	1.03	Drive Screw	2

SUB-ASSEMBLIES

J17.05P	Body, Including Plug
J17.10A	Release Valve Spindle
J17.23A	Filler Plug Gauge
J14.65A	Clamp Screw
J17.01A	Sub-Base (Includes Items 36-41-44-45-46-47)
J17.51A	Pump Plunger (Includes Items 10-11-12-13)
P208.70A	Pump Handle (Includes Items 48-49)

NOTE: No orders for parts can be filled unless both model and serial number of equipment is given.

GUARANTEE

All Blackhawk Jacks are guaranteed against defects in workmanship and material. In case of such defects, repairs and adjustments will be made on a no charge basis, providing jack or jack parts are returned to one of our Authorized Repair Service Stations or the factory at Milwaukee by prepaid transportation for inspection. Guarantee does not cover jacks worn out in service, damaged through abuse, overloading or accident. This guarantee is VOID if anything but BLACKHAWK HYDRAULIC JACK OIL is used in jack. Do NOT USE brake fluids.

BLACKHAWK AUTHORIZED REPAIR SERVICE STATIONS

BLACKHAWK MFG. CO. - - - MILWAUKEE 1, WIS.

1220-1.5M-351-2 - - - - -

Litho in U. S. of A.