

* Designates those parts included in repair kit #229850

REPLACEMENT PARTS	MODEL NO.	CAPACITY	DESCRIPTION
	72000D/E	1 1/2 TON	TRANSMISSION JACK

norco®

INDEX NO.	DESCRIPTION	PART NO.	REQ'D NO.
1	Frame Assy.	229275	1
2	Lift arm Assy.	229210	1
3	Guide Arm	229227	2
4	Trunion	229223	1
5	Trunion Arm	229224	2
6	Trunion Arm Rivet	229226	2
7	Pivot Pin	229222	1
8	Chain Tensioner	229299	1
9	Extension Arm	229301	4
10	Lock Screws	229302	4
11	Bolt	11013	4
12	Bolt	11179	4
*13	O-ring	229779	1
*14	Copper Seal	229781	1
*15	Backup Ring	229782	1
16			
17	"E" Retaining Ring	12139	4
18	Fore/aft Tilt Pin	229026	1
19	Saddle Base Plate	229303	1
20	Washer	229061	1
21	Nut	229062	1
22	Knob	229068	1
23	Expansion Pin	229069	1
24	Threaded Trunion	229067	1
25	Saddle Base Assembly	229060	1
26	Rear Side Tilt Screw	229066	2
27	Saddle Trunion	229083	1
28	Pivot Bolt	229059	1
29	Front Side Tilt Screw	229064	2
30	Bearing Container, Outside	229081	1
31	Bearing Assembly	229085	2
32	Bearing Container, Inside	229089	1
33	Saddle Base Clevis	229019	1
34	Retaining Ring	12141	4
35	Fore/aft Tilt Screw	229071	1

INDEX NO.	DESCRIPTION	PART NO.	REQ'D NO.
36	Retaining Ring	229077	2
37	Set Screw	229084	2
38	Grease Zerk Fitting	209048	1
39	Guide Arm Screw	209052	2
40	Caster Mounting Bolt	209133	8
41	Cotter Pin	209043	1
42	Cotter Pin	209057	1
43	Caster Mounting Nut	209124	16
44	Nut	209129	2
45	Lockwasher	209126	2
46	Flat Washer	2016	12
47	Retaining Ring	209044	1
48	Trunion Retaining Ring	209056	2
49	Caster Assy. Complete	229713	4
50	Handle Grip	229797	2
51	Handle	229798	1
52	Link	229799	2
53	Pin	229801	3
54	Retaining Ring	229802	6
55	Pump Piston	229803	1
*56	Oil Seal	229804	1
*57	Backup Ring	229806	1
*58	O-ring	229807	1
59	Pump Housing	229808	1
*60	Copper Seal	229809	1
61	Swivel Collar	229811	1
62	Hydraulic Block Assy. Complete	229800	1
63	Split Medium Lockwasher	229812	2
64	Release Valve Knob	229813	1
65	Expansion Pin	229814	1
66	Release Valve	229816	1
*67	O-ring	229817	1
*68	Checkball	229818	1
69	Cap Plug	229819	1
70	Overload Valve	229821	1

INDEX NO.	DESCRIPTION	PART NO.	REQ'D NO.
*71	Backup Ring	229822	1
72	Overload Spring	229823	1
73	Spring Guide	229824	1
*74	O-ring	229826	1
75	Valve Port Screw	229827	1
*76	O-ring	229828	1
77	Separator Bar	229829	1
*78	Checkball	229831	1
*79	Checkball	229832	1
80			
81	Hydraulic Block	229833	1
82	Hex Head Bolt	229834	2
83			
84	Filter	229836	1
*85	O-ring	229837	1
*86	Copper Seal	229838	1
87	Cylinder	229839	1
88	Bypass Screw	229841	1
89	Bypass Spring	229842	1
90	Spring Guide	229843	1
*91	Oil Seal	229844	1
92	Valve Pin	229846	1
93	Retaining Ring	229847	1
*94	U-cup Seal	229848	1
95			
96	Ram Bearing	229849	1
97	Bypass Bar	229851	1
98	Ram	229852	1
99	Reservoir Fill Plug	229853	1
100			
101	Reservoir	229854	1
*102	O-ring	229856	1
103	Cylinder Nut	229857	1
*104	O-ring	229858	1
105	Saddle Assy. Complete	72000A-2	1
	Repair Kit	229850	1

The asterisk * designates those parts included in repair kit #229850