

REPLACEMENT PARTS	MODEL NO.	CAPACITY	DESCRIPTION
	86000	6000 LBS.	MID-RISE ABOVE GROUND LIFT

norco®

INDEX NO.	DESCRIPTION	PART NO.	QTY.
1	Ramp assy.	860005	1
2	Retaining ring	860001	12
3	Inner ram assy.	860010	1
4	Center shaft	860002	2
5	Roller	860003	4
6	Retaining ring	860004	4
7	Bushing	860006	12
8	Shaft	860007	4
9	Outer ram assy.	860015	1
10	Roller shaft	860008	2
11	Bushing	860009	4
12	Hex bolt	860011	8
13	Lock washer	860012	8
14	Stopper bracket	860013	4
15	Spring pin	860014	4
16	Stopper	860016	4
17	Spring	860017	4
18	Adapter stopper assy.	860020	4
19	Swing arm	860018	4
20	Washer	860019	4
21	Castle nut	860021	4
22	Cotter pin	860022	4
23	Allen socket screw	860023	16
24	Flat washer	860024	16
25	Rubber pad	860026	4
26	Slide base	860027	4
27	Pad adapter assy.	860025	4
28	Stacking adapter	860028	4
29	Channel adapter	860029	4
30	5/16" - 18 hex nut	1082	4
31	Extension screw holder	860032	4
32	Slide base	860033	4
33	Flat washer	860034	4
34	Lockwasher	860036	4
35	Screw	860037	4
36	Extension screw adapter	860030	4

INDEX NO.	DESCRIPTION	PART NO.	QTY.
37	Velocity fuse	860035	2
38	Retaining ring	860038	2
39	Washer	860039	2
40	Spring	860041	2
41	Valve	860042	2
42	Housing valve body	860043	2
43	Short hydraulic line	860040	2
44	Long hydraulic line	860045	1
45	Adapter elbow	860044	4
46	Hex bolt	860046	2
47	Lockwasher	860047	2
48	Manifold	860048	1
49	Safety lock assy.	860050	1
50	Left cylinder assy.	860055	1
51	Right cylinder assy.	860060	1
52	90° elbow	860049	2
53	Left cylinder tube	860051	1
54	Right cylinder tube	860052	1
55	Vent plug	860053	2
56	Square head plug	860054	2
57	Nut	860056	2
58	Wear ring	860057	2
59	Packing	860058	2
60	Back-up ring	860059	2
61	Packing retainer	860061	2
62	O-ring	860062	2
63	Piston rod	860063	2
64	O-ring	860064	2
65	Wear ring	860066	2
66	Bushing	860067	2
67	Wiper	860068	2
68	O-ring	860069	2
69	Cylinder nut	860071	2
70	Retaining ring	860072	4
71	Piston pin	860073	2
72	Safety cam release lever	860074	1

Cylinder Seal Kit = 860110

INDEX NO.	DESCRIPTION	PART NO.	QTY.
73	Grip	860076	1
74	Lever	860077	1
75	Screw	860078	1
76	Safety lock cable	860065	1
77	Screw	860079	1
78	Cable adjuster	860081	1
79	Hex nut	860082	1
80	Nut	860083	2
81	Hex bolt	860084	1
82	Lock pipe	860086	1
83	Hex nut	860087	1
84	Lockwasher	860088	1
85	Cam lever	860089	1
86	Cable lock bolt	860091	1
87	Retaining ring	860092	1
88	Cam shaft	860093	1
89	Link	860094	1
90	Spring pin	860096	1
91	Spring pin	860097	1
92	Safety cam	860098	1
93	Spring	860099	1
94	Hex bolt	860101	1
95	Lock leg	860102	1
96	Trolley ~~assy.~~	860105	1
97	Flat washer, wheel	2074	4
98	Cotter pin	7056	2
99	Wheel	492005	2
100	Grip	479248	2
101	Electrohydraulic pump	860100	1
102	5/16" - 18 x 1" hex head bolt	11054	4
103	5/16" flat washer	2071	4
104	5/16" lockwasher	2119	4
105	Adapter	860103	3
106	5/16" - 18 nut	1082	4
107	1/2 ring with 2 screws	860104	1
108	Complete Trolley Assy.	860108	1
109	Fitting for Pump Hose	860095	1