SERIAL NUMBER SYSTEM

JACK MODEL NUMBER IS LAST 3 DIGITS OF 5 DIGIT NUMBER

SERIES LETTER

DAY OF THE MONTH



SERIAL NUMBER. Starts from 001 each day and can run up to 999.

IDENTIFIES THE YEAR:

A - 1973	E - 1977	I - not used
B - 1974	F - not used	J - 1980
C - 1975	G - 1978	K - 1981
D - 1976	H - 1979	L - 1982

MONTH. Starting with A for January, B for February, etc.

Serial Plate Model #	Capacity Tons	Description
601	30	Heavy Duty Hydraulic Jack
602	50	Heavy Duty Hydraulic Jack
603	100	Heavy Duty Hydraulic Jack
622	50	Air Operated Shop Press
630	1½	Service Jack w/Rubber Wheels
632	1½	Service Jack
633	1¼	Service Jack
635	1¼	Racing Jack
636	1	Service Jack
652	2	Service Jack
655	2	Service Jack
656	2	Service Jack w/Rubber Wheels
657	4	Service Jack w/Rubber Wheels
660	10	Service Jack w/Rubber Wheels
662	10	Air/Manuel Service Jack
666	2	Air/Manuel Service Jack
667	4	Air/Manuel Service Jack
688	1½	Hydraulic End Lift
689	1½	Air End Lift
692	7	Air End Lift
696	2½	Air End Lift
711	¼	Mechanical Transmission Jack
712	½	Mechanical Transmission Jack
714	¼	Hydraulic High Lift Transmission Jack
715	1	Mechanical Transmission Jack
716	½	Hydraulic Transmission Jack
717	1	Hydraulic Transmission Jack
729	20	Air Operated Hydraulic High Height Service Jack
730	20	Air Operated Hydraulic Medium Height Service Jack
731	20	Air Operated Hydraulic Low Height Service Jack
736	7 ea.	Twin Air Lifts
765	¾	Wheel Dolly
766	1¼	Wheel Dolly
770	⅜	Engine Stand
773	⅝	Allison Automatic Transmission Stand
774	⅝	Engine Stand
801	½	Knock-Down Crane
802	¾	Knock-Down Crane
803	½	Truck Mounted Crane
804	1	Knock-Down Crane
805	2	Knock-Down Crane
806	½	Shop Crane
809	¾	Shop Crane
812	1	Shop Crane
815	2	Shop Crane
827	1¾	Mobile End Lift (Air Operated)